

Vibration Monitoring and Machine Protection Systems

1010 East Main Street, League City, TX 77573 Phone:281.334.0766 Fax: 281.334.4255 www.stiweb.com / www.stiwebstore.com

CMCP797-2 **Dual Channel Active Buffer Module**



Features:

- Two Input / 6 Outputs
- Accepts Proximity Probes, Accelerometers and Velocity Sensors
- BNC Buffered Output Per Sensor Input
- Two Hardwired Buffered Outputs Per Sensor Input
- +/- 24VDC Powered
- Onboard Constant Current Power for IEPE Sensors
- Power On LED
- Din Rail Mountable
- DC Coupled (BOV or Gap Voltage Passed to Output)
- Accepts TBUS Connections

Typical Applications

Online Monitoring System Signal Splitting, Sensor Powering, BNC Buffered Signal Access

Specifications:

Accuracy: Input: Output:

Power Input: Power Consumption: Frequency Range: Input Impedance: Constant Current Diode: Output Impedance: Dimensions:

Environmental

Operating Temperature: Storage Temperature: Relative Humidity:


0.1% Basic AC and DC Signals Proximity Probes, IEPE Accelerometers and Velocity Sensors


Three (3) Active Buffered Outputs Per Channel 2 Hardwired Buffered Outputs Per Input 1 BNC Buffered Output Per Input

+/-24VDC 35mA Max OHz to 150kHz @ -3dB 100k Ohms 4mA <100hms 3.86"x0.87"x4.82" (98x22x122mm)

 -20° C to $+80^{\circ}$ C (-4° F to $+176^{\circ}$ F). -55°C to +125° C (-67° F to +257° F). 0 - 95% Non-Condensing.

Dimensions:





Instructions

The CMCP797-2 accepts up to two inputs from either +24VDC or -24VDC powered sensors. The internal DIP switches must be placed in the proper position prior to being using.

Switch #1 (S1)

The Constant Current Power Switch (S1), when in the ON position, will provide constant current power to both sensor inputs. Constant Current Power is used when the CMCP797-2 must power an IEPE accelerometer or velocity. To turn on Constant Current Power place the switch in the ON position (to the left). When sensor power is not required, for example when the signal input comes from a buffered output on another system or when the sensor is externally powered, S2 must be placed in the Off position (to the right).

Switch #2 (S2)

The Signal Input Switch (S2) selects the sensor input signal type. For +V output sensors, such as an IEPE accelerometer or velocity sensor, the switch will be placed in the + position (to the right). For eddy current probes (or other -V output sensor) the switch will be placed in the – position (to the left).

Buffered Outputs

The CMCP797-2 provides three (3) buffered outputs per input. For each channel, two buffered outputs are located on the screw terminal blocks and one buffered output on the front panel BNC connector.

